

SIDECOVER

WASTE SYSTEMS

The SIDECOVER is the most reliable sheeting system for walking floors and ejector trailers on the market.



transcover - automatic +44 (0)1322 666601



This system is fully automatic for walking floor and ejector trailers and can also be used for tipping trailers with side walls of at least (2.5m). The sidecover will deal with most heaped loads.

Operates from an independent hydraulic power pack or direct from the donkey engine with easy maintenance.

The driver operates the system from the side of the trailer by push button controls. The whole tarp is lifted by the front arm and the tarp folds flat to

the side of the trailer body for restricted loading areas.

We have taken the original system everyone knows and listened to the improvements that our customers felt were needed. Now, because we manufacture for ourselves, we have been able to implement them.

“we won't be beaten on quality or price!”

- Side mounted covering system.
- Covers heaped loads.
- Fast operation.
- Electro/hydraulic operation.
- Leaves one side unobstructed.
- Covers in 20 seconds.
- Supplied in kit form.
- Saves up to 2 hours covering time per day.
- Self contained hydraulics.
- Suitable for ejector, walking floor and tilting trailers.
- Fully automatic.
- Easy maintenance.



TRANSCOVER (EUROPE) LTD
WESTED LANE
SWANLEY
BR8 8EE

t: +44 (0)1322 666601
 f: +44 (0)1322 666615
 e: sales@transcover.com
 w: transcover.com



www.transcover.com

Frequently asked questions

1.) What size trailer will the SIDECOVER cover?

The Sidecover will cover all Walking Floor, Ejector trailers, and also tipping Bulklers with a side wall greater than 2.5m.

2.) What sheet does the SIDECOVER come with?

The Sidecover comes with a net as a solid sheet is not recommended with this system.

3.) Will the SIDECOVER cope with heaped loads?

Yes the net is not fitted taught and this allows for heaped and awkward loads.

4.) What powers the SIDECOVER?

The Sidecover is operated by either a electrohydraulic pump or is plumbed through the trailers hydraulics with a wet kit.

5.) How long does it take to fit the SIDECOVER?

It usually takes a day and a half to fit, and we offer a fitting service if required, although the system comes with full fitting instructions.

6.) What holds the SIDECOVER down?

The Sidecover arm is operated by a rack and pinion and this stops back lift once the arm is in the closed position.

7.) What side do I need to fit the SIDECOVER to?

Either, simply request what side you wish the system to remain clear for loading and we can accommodate you.

8.) What is the warranty on the SIDECOVER?

1 year warranty on all parts and 90 day workmanship on the sheet.