

AUTOCOVER

WASTE SYSTEMS

The Autocover is the most popular system for hookloaders. Proven and reliable design, manufactured in the UK for the UK market.



transcover - automatic +44 (0)1322 666601



The Autocover is a hydraulically operated automatic sheeting system mounted to a hookloader or draw-bar trailer to cover open top containers.

The Autocover system is capable of covering containers of various sizes, heights and lengths.

If desired, the Autocover can cover loads with minimal height clearance above the container.

The Autocover is designed not to extend beyond the rear of the container. The container size can range from 14 cu. mt. to 46 cu. mt.

The arms have a low profile design to reduce chances of sitting containers down on them, therefore avoiding damage. The sheet is rolled out above the load, not dragged over the load.

The arms are fitted with deflectors to help push them out of the way when damaged containers come in contact, this reduces the chance of bending and damaging them.

"we won't be beaten on quality or price!"

- Simple and safe to use – easy to install.
- Less than 25 seconds to extend and retract.
- Requires minimal maintenance.
- Best Quality and Price on the Market.
- System comes ready to install, powder coated finish.
- Sheet is laid on the load, reducing sheet damage.
- Quick operation, covers all size containers.



**TRANSCOVER
WESTED LANE
SWANLEY
BR8 8EE**

t: +44 (0)1322 666601
f: +44 (0)1322 666615
e: sales@transcover.com
w: transcover.com



www.transcover.com

Frequently asked questions

1.) Does it cover all size containers?

Yes the Autocover covers all size containers, it has been designed to fit all.

2.) Does the sheet have side flaps?

The sheet comes with standard side flaps, if you have a particular difficult load try our x-span sheet.

3.) How is the Autocover powered?

The Autocover runs off of the trucks hydraulics, or with an Electro-Hydraulic power pack.

4.) Can I retrofit the Autocover?

The Autocover is designed to easily retrofit to existing Hook-loaders or to new builds.

5.) How do you change out the tarp?

Easy operation - just follow the printed instructions.

6.) How long does it take to fit?

The Autocover has been designed so it can be easily fitted by someone with minimal knowledge of welding and hydraulics. We also have trained staff who can fit in a day and half, and a network of fitting agents nationwide to take care of your needs.

7.) What about heaped loads?

Autocover allows you to raise the tarp over peaked loads, and lays the sheet onto the load rather than dragging, this minimises sheet damage.

8.) What is the warranty on the Autocover?

There is a one year warranty on all of the system and hydraulics. The tarp has a 90 day manufacturing warranty on workmanship.